

### To connect the audio cables

MuTiVieW requires a TV WONDER card. For proper audio performance, ensure that the audio outputs from the ALL-IN-WONDER 9700 PRO and the TV WONDER are connected to **different inputs** on the sound card. The following instructions describe one method of connecting the audio cables. Other connection schemes are possible, depending upon the type of sound card in your computer.

When you connect the audio cables, make note of the name of the sound card's audio connectors. During initialization of the Multimedia Center, you will be prompted for the name of the connector you chose.

ATI Card		Sound Card Audio Connector
ALL-IN-WONDER 9700 PRO	Connects to:	.....
TV WONDER	Connects to:	.....

Using the illustration as a guide, follow the steps below to make the audio connections between your ALL-IN-WONDER 9700 PRO, TV WONDER, and sound card.

- 1 Using the external audio cable supplied with the TV WONDER, connect the audio output from the TV WONDER to an audio input (usually LINE IN) on your sound card.
- 2 Using the internal CD audio cable, connect the small, white CD AUDIO plug on the ALL-IN-WONDER 9700 PRO to your sound card's CD AUDIO IN connectors (refer to your sound card's manual).



## MuTiVieW™ Installation and Setup User's Guide

This guide explains how to install your ALL-IN-WONDER 9700 PRO and TV WONDER cards, and how to connect their audio outputs to your sound card.



- All references to TV WONDER apply to the ATI TV WONDER or TV WONDER VE products.
- TV WONDER USB Edition is not supported,
- You must **uninstall** any previous version of the Multimedia Center before proceeding.
- If you are installing a REMOTE WONDER for the first time, do not connect it until you have installed the ATI software. See Step 12.

### To install your ALL-IN-WONDER 9700 PRO

- 1 Ensure that you have an up-to-date AGP driver installed for your motherboard. Check with the motherboard manufacturer or visit the ATI Website for more details:  
<http://www.ati.com/support/faq/agpchipsetdrivers.html>.
- 2 Use **Add/Remove Programs** to uninstall your existing graphics card drivers and remove any control panels or other software that is intended to function with your existing graphics card. Restart your computer if prompted.
- 3 In Windows 2000 or Windows Me, install a basic VGA display driver.
- 4 Shut down your computer, and then turn off the power or unplug it.
- 5 Disconnect the monitor, and remove the existing graphics card (refer to your system manual for instructions on removing the cover.)
- 6 Install the ALL-IN-WONDER 9700 PRO into the AGP slot, ensuring that the card is properly seated before replacing the bracket screw.
- 7 Connect the auxiliary power cable supplied with the ALL-IN-WONDER; refer to the *ALL-IN-WONDER 9700 PRO Installation and Setup User's Guide* or the *Installation Poster* for additional details.

- 8** Using the internal CD audio cable, connect the small, white CD AUDIO plug on the ALL-IN-WONDER 9700 PRO to the sound card's CD AUDIO IN connector (refer to your sound card manual). If you choose a different connector, be sure to make note of its name. See the illustration on page 4.
- 9** Double-check all connections and bracket screws, turn on the system power, and then start the computer.
- 10** When **New Hardware** is detected, click **Cancel**, and let Windows finish loading.
- 11** Insert the ALL-IN-WONDER 9700 PRO Installation CD. If the CD does not Autorun, navigate to the CD, double-click **Atissetup.exe**, click **Software Install**, and then follow the on-screen instructions.
- 12** When the software installation is complete, shut down your computer.  
*Optional: Now is a good time to connect the REMOTE WONDER receiver to a USB port on your computer.*
- 13** Restart the system.  
*Windows will finish installing the final components. You are now ready to set your desired resolution and start the TV application. The Initialization Wizard will guide you through the audio setup.*

### ***To install your TV WONDER***

- 1** Shut down your computer, and then turn off the power or unplug it.
- 2** Install the TV WONDER in a PCI slot, ensuring that the card is properly seated before replacing the bracket screw.
- 3** Using the external audio cable supplied with the TV WONDER, connect the audio output from the TV WONDER to an audio input (usually LINE IN) on your sound card. If you choose a different connector, make note of its name. See the illustration on page 4.
- 4** Double-check all connections and bracket screws, replace the PC cover, turn on system power, and then restart the computer.  
*During the installation, you may see warnings that the drivers are not certified by Microsoft; please continue with the installation.*
- 5** Restart your computer if prompted.
- 6** Launch TV. The Initialization Wizard will prompt you to enable MultiView, and will assist with the audio setup described in Step 3.